


PACKAGE CONTENT
设备包装清单
CONTENIDO DEL PAQUETE
CONTENU DU PAQUET
PACKUNGSINHALT
CONTENUTO DELLA CONFEZIONE
КОМПЛЕКТ ПОСТАВКИ
CONTEÚDO DA EMBALAGEM

WP826 PORTS AND BUTTONS
WP826 接口和按钮
WP826 PUERTOS Y BOTONES
PORTS ET BOUTTONS DE WP826
WP826 PORTS UND TASTEN
PORTE E PULSANTI DEL WP826
РАЗЪЕМЫ И КНОПКИ WP826
PORTAS E BOTÕES WP826




| DEFAULT Wi-Fi | |
|---------------|-------------|
| SSID | wp_master |
| | wp!987@dmin |



WP826 Phone
WP826手机
Teléfono WP826
Téléphone WP826
WP826-Telefon
Telefono WP826
WP826-телефония
Telefone WP826



Charging Station
充电座
Estación de Carga
Station de Charge
Ladestation
Stazione di carica
Зарядная станция
Estação de Carga




WP826

Cordless Wi-Fi IP Phone

Quick Installation Guide




Handset Belt Clip
手柄皮带夹
Cinturón Clip para Auricular
Support Ceinture du Combiné
Handset Gürtelclip
Clip per cintura per ricevitore
Зажим для крепления к поясному ремню
Clip de cinto para o Handset



Rechargeable Battery
充电电池
Batería Recargable
Batterie rechargeable
Wiederaufladbare Batterien
Batterie ricaricabili
Аккумуляторные батареи
Bateria Recarregável





Type-C 5V power adapter
Type-C 5V电源适配器
Adaptador de corriente tipo C de 5 V
Adaptateur secteur de type C 5 V
Typ-C-5-V-Netzteil
Adattatore di alimentazione di tipo C da 5 V
Адаптер питания типа C 5 V
Adaptador de energia tipo C 5V



Quick Installation Guide
快速安装手册
Guía de Instalación rápida
Guide d'Installation Rapide
Kurz- Installationsanleitung
Guida rapida diinstallazione
Краткие руководства по
Guia de Instalação Rápido

| English | 简体中文 | Español | Français | Deutsch | Italiano | Русский | Português |
|--|-----------------|--|---|--|---|---|--|
| 1 Noise Canceling Microphone | 降噪麦克风 | Micrófono con cancelación de ruido | Microphone antibruit | Mikrofon mit Geräuschunterdrückung | Microfono con cancellazione del rumore | Микрофон с шумоподавлением | Microfone com cancelamento de ruído |
| 2 Type-C Headphone & charging port | Type-C 耳机和充电端口 | Puerto de carga y auriculares Type-C | Port pour casque et chargeur de type C | Typ-C-Kopfhörer- und Ladeanschluss | Porta per cuffie e ricarica Type-C | Порт для наушников и зарядки Type-C | Porta tipo C para auscultadores e carregamento |
| 3 PTT key | PTT 键 | Tecla PTT | Touche PTT | PTT Taste (Push to Talk) | Tasto PTT | Кнопка PTT | Tecla PTT |
| 4 Volume Down Key | 音量降低键 | Tecla de Bajar Volumen | Touche Volume Bas | Taste zur Reduzierung der Lautstärke | Tasto Reduzione Volume | Кнопка уменьшения громкости | Tecla baixar volume |
| 5 Volume Up key | 音量提高键 | Tecla Subir Volumen | Touche Volume Haut | Taste zur Erhöhung der Lautstärke | Tasto Aumento Volume | Кнопка увеличения громкости | Tecla subir volume |
| 6 LED indicator | LED指示灯 | Indicador LED | Indicateur LED | LED Anzeige | Indicatore LED | СИДиндикатор | Indicador LED |
| 7 1 / Voicemail key | 1/语音信箱键 | 1 / Tecla de correo de voz | 1 / Touche Messagerie Vocale | 1 / Sprachnachrichten Taste | 1 / Tasto Casella vocale | 1 / Кнопка Голосовая почта | 1 / Tecla de Correio de Voz |
| 8 * / Symbolic key / Silent Mode | * / 符号键 / 静音模式 | * / Tecla simbólica / Modo silencioso | * / Touche symbolique / Mode silencieux | * / Symbolische Taste / Stiller Modus | * / Tasto simbolico / Modalità silenziosa | * / Символическая клавиша / Беззвучный режим | * / Tecla simbólica / Modo silencioso |
| 9 Microphone | 麦克风 | Micrófono | Microphone | Mikrofon | Microfono | Микрофон | Microfone |
| 10 # / Input method switching / Lock key | # / 输入法切换 / 锁定键 | # / Conmutación del método de entrada / Tecla de bloqueo | # / Commutation de la méthode d'entrée / Touche de verrouillage | # / Umschalten der Eingabemethode / Sperrtaste | # / Commutazione del metodo di ingresso / Tasto di blocco | # / Переключение способа ввода / Клавиша блокировки | # / Comutação do método de entrada / Tecla de bloqueio |
| 11 On-hook /Power key | 挂机或电源键 | Cuelgue / tecla de encendido | Décrocher / Touche d'Appel | Auflegen und An/Aus Taste | Tasto Accensione / aggancio | Кнопка окончания вызова / питания | On-hook / Tecla de power |
| 12 Mute /Shortcut Key | 静音 /快捷键 | Silenciar /Tecla de acceso directo | Muet /Touche de raccourci | Stumm /Tastenkürzel | Silenzia /Tasto di scelta rapida | Выключить звук / Быстрая клавиша | Mudo /Tecla de atalho |
| 13 Proximity Sensor | 近距离传感器 | Sensor de proximidad | Captur de proximité | Nahbereichsensor | Sensore di prossimità | Датчик приближения | Sensor de proximidade |



Grandstream Networks, Inc.

126 Brookline Ave, 3rd Floor
Boston, MA 02215. USA
Tel : +1 (617) 566 - 9300

| | | | | | | | | |
|----|----|----|----|----|----|--------|----|----|
| BE | BG | CZ | DK | DE | EE | IE | EL | LI |
| ES | FR | HR | IT | CY | LV | LT | LU | CH |
| HU | MT | NL | AT | PL | PT | RO | SI | TR |
| SK | FI | SE | NO | IS | UK | UK(NI) | | |

In the UK and EU member states, operation of 5150-5350 MHz is restricted to indoor use only.



For Certification, Warranty and RMA information, please visit www.grandstream.com

